

Download the multiple transmitter manual on the download page for a detailed explanation.

The more expensive AM1000C model has a wire serial (RS485) interface that can be used to link (phase) transmitters together with wire or other high speed link.

You would only need this feature if you were going to phase multiple transmitters along a highway or on a large property.

For almost all the AM1000E will work, it can be used as a multiple transmitter when placed in different locations (Not the same location)